


SZELEC



SPK-06-C系列

杂物电梯磁感撞弓

Dumbwaiter Magnetic Induction

使 用 说 明 书
INSTRUCTION SHEET

感谢您购买本公司开发生产的开关产品，请您在使用本产品前仔细阅读本使用说明。


Thanks for purchasing the switch products developed and produced by us!

Please read the instructions carefully before using the products.


济南上智电气有限公司

● 单速系统安装指导 INSTALLATION of single-speed elevator control system

- ① 磁感撞弓安装在支架上(单速使用1个撞弓)
install it on the bracket (single-speed elevator control system uses one)
- ② 螺栓安装或焊接安装于轿厢上
Bolt installation or welding on the car



③ 装配完成示意图 Final Schematic




底层开关装配示意图
Hoistway Wiring Schematic


变频系统安装指导

INSTALLATION of frequency-variable speed control system

- ① 磁感撞弓安装在支架上 (变频使用3个撞弓) ② 螺栓安装或焊接安装于轿厢上
 Install it on the bracket (frequency-variable speed elevator control system uses three) Bolt installation or welding on the car



③ 装配完成示意图 Final Schematic



底层开关装配示意图
 Hoistway Wiring Schematic

